


Art. 150.1960



Art. 150.1960

Art.-Nr.	Description	Beschreibung	Menge Qty.
150.1960-R001P	Inlet connector	Stecknippel	1
150.1960-R002P	Closing cap	Verschlusskappe	1
150.1960-R003P	Spring	Feder	1
150.1960-R004P	Steel ball	Stahlkugel	1
150.1960-R005P	Valve housing	Ventilgehäuse	1
150.1960-R006P	Valve screw	Ventilschraube	1
150.1960-R007P	Gasket	Abdichtplatte	1
150.1960-R008P	O-Ring for control valve	O-Ring für Regelventil	3
150.1960-R009P	control valve	Regelventil	1
150.1960-R010P	O-Ring	Dichtring	2
150.1960-R011P	Housing joint	Gehäuseverschraubung	1
150.1960-R012P	Exhaust housing	Abluftgehäuse	1
150.1960-R013P	Housing connector	Verbindungsverschraubung	1

Art.-Nr.	Description	Beschreibung	Menge Qty.
150.1960-R014P	Bushing	Buchse	1
150.1960-R015P	Inlet connector for exhaust hose	Anschlussnippel für Abluftschlauch	2
150.1960-R016P	Exhaust hose	Abluftschlauch	1
150.1960-R017P	Vacuum valve	Unterdruckventil	2
150.1960-R018P	Manometer	Manometer	1
150.1960-R019P	Distributor housing	Verteilergehäuse	1
150.1960-R020P	Quick coupling	Schnellkupplung	1
150.1960-R021P	Screw connector	Schraubanschluss	2
150.1960-R022P	Diagnosis tube with connector	Diagnoseschlauch mit Schraubanschluss	1
150.1960-R023P	Adapter quick connector	Adapterschnellkupplung	1