


Art. 512.3400



Art. 512.3400

Art.-Nr.	Description	Beschreibung	Menge Qty.
512.1015-R001P	Hammer Case	Hammergehäuse	1
512.1015-R002P	Press-Oiling Cup	Schmiernippel	1
512.1015-R003P	Hammer Case Handle	Griffeinheit	1
512.1015-R004P	Hex Screw Spring Washer	Unterlegscheibe	4
512.1015-R005P	Hex Screw	Schraube für Griff	4
512.1015-R006P	Bushing	Laufbuchse	1
512.1015-R007P	Retainer	Stecknusshaltering	1
512.1015-R008P	O-ring	O-Ring für Antriebs 4kant	1
512.3400-R001P	3/4" Anvil Short Type	Amboss 3/4" Kurz	1
512.1015-R010P	Hammer Pin	Arretierungsstift	2
512.1015-R011P	Hammer Frame	Hammerkäfig	1
512.1015-R012P	Hammer Dog	Hammer	2
512.1015-R013P	Front Seal washer	Dichtungsring	1
512.1015-R014P	Bearing	Kugellager	1
512.1015-R015P	Front Cylinder Plate	Vordere Verschlussplatte	1
512.1015-R016P	Rotor	Rotor	4
512.1015-R017P	Rotor Blade	Rotorblatt	6
512.1015-R018P	Air Cylinder	Rotorgehäuse	1
512.1015-R019P	Pin	Pin	1
512.1015-R020P	Rear Cylinder Plate	Verschlussplatte	1
512.1015-R021P	Bearing	Kugellager	1
512.1015-R022P	Screw	Schraube für Umschalthebel	1

Art.-Nr.	Description	Beschreibung	Menge Qty.
512.1015-R023P	O-ring	O-Ring	1
512.1015-R024P	O-ring	O-Ring	1
512.1015-R025P	Reverse Switch	Umschalter	1
515.1200-R031P	Trigger	Betriebsschalter	1
515.1200-R033P	Trigger Spring	Feder	1
512.1015-R026P	O-ring	O-Ring	1
512.1015-R027P	Housing	Gehäuse	1
512.1015-R028P	Ping	Splint	1
512.1015-R029P	Rear Seal Washer	Hintere Dichtung	1
512.1015-R030P	End cap	Gehäusedeckel	1
515.1200-R025P	Steel Ball	Stahlkugel	1
515.1200-R024P	Steel Ball Spring	Feder	1
512.1015-R031P	Outside Reverse Switch	Umschalthebel	1
512.1015-R032P	Hex Screw	Schraube für Umschalthebel	4
512.1015-R033P	Air Inlet Insert	Hülse	1
512.1015-R034P	Exhaust Deflector	Abluftdeflektor	1
515.1200-R039P	Intake Gasket	Dichtungsring	1
515.1200-R040P	Throttle valve	Dichtungsring	1
515.1200-R041P	Throttle	Druckventil	1
512.1015-R035P	Throttle Spring	Ventilfeder	1
512.1015-R036P	Washer	O-Ring	1
512.1015-R037P	Air Inlet	Lufteinlassschraube	1