


Art. 515.3179



Art. 515.3179

Part. No	Art.-Nr.	Beschreibung	Description	Menge Qty.
1	515.3179-R001P	Schraube	Screw	1
2	515.3179-R002P	Spannfutter	Chuck	1
3	515.3179-R003P	Unterlegscheibe	Packing	1
4	515.3179-R004P	Lager	Bearing	1
5	515.3179-R005P	Frontabdeckung	Front cover	1
6	515.3179-R006P	Rotor	Rotor	1
7	515.3179-R007P	Kevlar-Blätter	Kevlar blades	4
8	515.3179-R008P	Zylinder	Cylinder	1
9	515.3179-R009P	Lager	Bearing	1
10	515.3179-R010P	Untere Abdeckungsbasis	Lower cover base	1
11	515.3179-R011P	Gehäuse	Housing	1
12	515.3179-R012P	Hauptkörper	Main body	1

Part. No	Art.-Nr.	Beschreibung	Description	Menge Qty.
13	515.3179-R013P	Auspuffrohr	Exhaust pipe	1
14	515.3179-R014P	Lufteinlassrohr	Air intake pipe	1
15	515.3179-R015P	Fixierstift	Fixing pin	1
16	515.3179-R016P	O-Ring	O-ring	2
17	515.3179-R017P	Luftmengenregler	Air volume regulator	1
18	515.3179-R018P	O-Ring	O-ring	1
19	515.3179-R019P	Schraube	Screw	1
20	515.3179-R020P	Fixierhülse	Fixing sleeve	1
21	515.3179-R021P	Schwarzes Ansaugrohr	Black intake pipe with female nozzle set	1
22	515.3179-R022P	Schalldämpferrohr	Muffler pipe	1
23	515.3179-R023P	Maulschlüssel	Spanners	2